

RNA-seq data processing and analysis with ARMOR



STA426 – 09.11.2020

Katharina Hembach




Figure 1

Overview of the experimental steps in an RNA sequencing (RNA-seq) protocol. The complementary DNA (cDNA) library is generated from isolated RNA targets and then sequenced, and the reads are mapped against a reference genome or transcriptome. Downstream data analysis depends on the goal of the experiment and can include, among other things, assessing differential expression, variant calling, or genome annotation.



ARMOR workflow


- Automated = snakemake



- Reproducible = conda and GitHub



- MO**dular = snakemake rules + configuration file
- RNA**-seq



Preprocessing of RNA-seq reads

1. Quality filtering & adapter trimming
(remove reads with bad quality & adapter sequences)
2. Alignment to reference genome
3. Quantification of feature of interest
(gene or transcript)

Quality control

- **FastQC**

<https://www.bioinformatics.babraham.ac.uk/projects/fastqc/>

- **MultiQC** <https://multiqc.info/>

- aggregates FastQC results from multiple samples, as well as Salmon and STAR output


- # reads, read length, read quality, GC content, % duplicated reads, adapter contamination, ...

- Tools for quality filtering/adapter trimming:


- cutadapt, TrimGalore!, Trimmomatic, FASTX-toolkit, ...

Alignment

a Spliced alignment against genome



b Unspliced alignment against transcriptome



STAR

<https://github.com/alexdobin/STAR>

HISAT2

<http://ccb.jhu.edu/software/hisat2/index.shtml>


Salmon

<https://combine-lab.github.io/salmon/about/>


kallisto

<https://pachterlab.github.io/kallisto/about>


Variants of differential expression




b Differential gene expression




c Differential gene expression



d Differential transcript usage



e Differential gene expression and differential transcript usage



* Differential transcript expression in group B relative to group A

Statistical analysis

- **Differential gene expression:** Which genes change in expression in different genotypes, treatments, time points, ...?

(edgeR <http://bioconductor.org/packages/release/bioc/html/edgeR.html> or DESeq2 <http://bioconductor.org/packages/release/bioc/html/DESeq2.html>)

- **Differential transcript usage:** Does the transcript composition of a given gene change?

(DRIMseq <https://bioconductor.org/packages/release/bioc/html/DRIMSeq.html>)

- **Gene set analysis:** are the DE genes enriched for a specific gene annotation category?

(*camera*) function from limma R package

<https://academic.oup.com/nar/article/40/17/e133/2411151>)

HOW TO ORGANIZE YOUR SOFTWARE?



<https://docs.conda.io/projects/conda/en/latest/user-guide/getting-started.html>

- Open source package and environment management system for any programming language.
- quickly install, run and update packages and their dependencies
- packages are stored on different “channels” (locations)
- you need to specify the channel(s) when installing things
- bioconda is the channel for bioinformatics software

<https://bioconda.github.io/>



Conda environments

- you can manage packages/programs and their dependencies in environments
 - no interaction with other environments
 - easy to control package/language versions and avoid conflicts
 - you can export an environment to a YAML file (<https://yaml.org/spec/1.2/spec.html>) and easily share it
- reproducibility!

Snakemake



+



=



<https://snakemake.readthedocs.io/en/stable/>

- workflow management system
- reproducible and scalable data analyses
- specify **rules** that describe how to create output files from input files
- file/rule dependencies are automatically determined
- rules can use shell commands, python code or external python/R scripts
- runs on laptops, clusters, the cloud without modifications
- you can automatically deploy required software with conda

What does it look like?

- Define Snakefile with rules

```
1 rule hello:
2     input:
3         "my_name.txt"
4     output:
5         "hello.txt"
6     shell:
7         "NAME=$(cat {input}); "
8         "echo Hello $NAME! > {output}"
```

- Execute with

```
(snakemake) katharina@IMLS-NBM-KHE:~/Desktop$ snakemake hello --cores 1
```

Snakemake: useful commands

`--help` to get detailed help message

`--use-conda` to run rules in conda environments

`-n` dry run → only display what would be done but do not execute anything

`-p` print shell commands that will be executed

`-r` print reason for each executed rule

can be combined in `-npr`

`-l` list all available rules

`--cores` to use at most this number of cores in parallel


`--configfile` path to configuration file (e.g. config.yaml)

ARMOR WORKFLOW






ARMOR workflow






ARMOR workflow





ARMOR workflow


Transcript
abundance
estimation





ARMOR workflow


Data
import into
R





ARMOR workflow


Differential gene
expression
analysis &
gene set
enrichment





ARMOR workflow


Differential
transcript usage






ARMOR workflow


Data export and
visualisation






iSEE visualization
of the ARMOR
output

<https://bioconductor.org/packages/release/bioc/html/iSEE.html>





ARMOR benchmarks all rules.

We can plot the required resources for the generation of the output files.

ARMOR: useful commands

- `snakemake -npr` to see what snakemake will be executing
- `snakemake setup` to see if all required software is available
- `snakemake checkinputs` to see if your specified design and contrast matrix is valid

Notes

- If you use renku, select at least 2GB of memory (STAR needs a lot).
- Fork one of these renku projects and start an environment:
<https://renkulab.io/projects/rok.roskar/sta426hs2020> or
https://renkulab.io/projects/mark.robinson/armor_bioc311
- You might want to relax the filtering of lowly expressed genes (edgeR-dge.Rmd).
- DRIMSeq might fail because there are not enough genes (you can disable it in config.yaml).